

NEXTORCH

纳丽德

多用工具钳系列使用说明书 Multi-tools series User Manual

注意事项 Safety Consideration

纳丽德多用工具钳含有锋利的刃口或顶端较尖的工具, 在开、合及使用工具钳时请务必小心, 避免意外的伤害。使用前请仔细阅读使用说明书。

As with most tools and pocket knives, several blades have sharp edges or points. Be extremely careful not to cut or pinch yourself with blades or handles when opening, closing or using your multi-tool. Please read the user manual carefully.


产品保养 Maintenance

1. 使用完清洗干净, 特别是将盐渍、油脂、污垢等彻底洗净, 并且确保无碎片或粉尘堵塞, 然后用布擦干。
2. 必要时需要在轴心部位滴上润滑油, 以确保能使用顺畅。
3. 平时可用润滑脂或机油涂擦, 以防止腐蚀生锈。

1. Clean your multi-tool after use, especially pay attention to the saline, grease, dirt and other, and ensure that no debris or dust clogging, and then dry it.
2. If necessary, lubricating oil should be dripped on the axis to ensure smooth operation.
3. Usually, grease or oil can be applied to prevent corrosion and rust.

保修条款 Warranty

1. 一年免费保修: 纳丽德产品自售出日起一年内, 在正常使用的情况下, 若出现质量问题, 可享受免费维修服务。
 2. 因使用不当或擅自改装、维修而引起的产品损坏, 或超过一年保修期的产品, 纳丽德将提供有偿维修服务。
1. NEXTORCH provides free maintenance service for products with quality problems under normal use within 1 year since the purchase date.
2. NEXTORCH will provide paid maintenance service for products damaged by improper use, refitting or beyond the one-year free warranty period.



- | | | | |
|------------------------------|---------------------------|--|---|
| 1 尖嘴钳
Needlenose Pliers | 2 标准钳
Regular Pliers | 3 切线钳
Premium Replaceable
Wire Cutters | 4 硬线钳
Premium Replaceable
Hard-wire Cutters |
| 5 粗线钳
Thick-wire Cutters | 6 木锯
Saw | 7 主刀
Knife | 8 十字螺丝刀
Phillips Screwdriver |
| 9 割绳刀
Line Cutter | 10 剥线刀
Wire stripper | 11 开罐器
Can opener | 12 开瓶器
Bottle Opener |
| 13 一字螺丝刀
Flat Screwdriver | 14 玻璃破碎器
Glass Breaker | 15 剪刀
Scissors | 16 刻度尺
Ruler |